



PROFI 58 R OP

Instrukcja montażu


Installation instructions
Instructions de montage
Montageanleitung

IP44




230 V
50 Hz




T5	A
14/24W	600mm
21/39W	900mm
28/54W	1200mm
35/49W	1500mm



	A
14/24W	585mm
21/39W	885mm
28/54W	1185mm
35/49W	1485mm




PL - Rozłączyć zapięcie przed wymianą lampy.
UK - Disconnect the unit before changing the lamp.
F - Debrancher l'appareil avant de changer la lampe.
D - Von den Auswechseln der lampe die Leuchte von der Netzspannung trennen.




P.U.H. "IMPERIAL" ZPChR Sp.J. Donat Król, Dariusz Król
ul. Kofobrzaska 8E, 78-200 Białogard
tel. +48 94 312 78 20, tel./fax. +48 94 312 78 69
email: office@imperial.pl
NIP 672-000-62-93

imperial®


①




②




③




④



⑤



PL - Rozłączyć zapięcie przed wymianą lampy.
UK - Disconnect the unit before changing the lamp.
F - Debrancher l'appareil avant de changer la lampe.
D - Von den Auswechseln der lampe die Leuchte von der Netzspannung trennen.



P.U.H. "IMPERIAL" ZPChR Sp.J. Donat Król, Dariusz Król
ul. Kofobrzaska 8E, 78-200 Białogard
tel. +48 94 312 78 20, tel./fax. +48 94 312 78 69
email: office@imperial.pl
NIP 672-000-62-93

imperial®